

Installation Instructions for JLT PCV Pre-Filter

96-04 Cobra:

Driver's side: Pull out your PCV valve, screw Pre-Filter into grommet in valve cover, reinstall PCV valve into the grommet in the Pre-Filter and hook up factory PVC line as shown:



Passenger side: Pull out hose and fitting from grommet in valve cover. Screw Pre-Filter into grommet, screw 90 deg. fitting into Pre-Filter and reconnect hose as shown:



03-04 MACH I:

Driver's side: Pull off rubber 90 deg. elbow and set aside. Use short section of 5/8 hose to connect the PCV valve to the Pre-Filter, screw 90 deg. fitting into grommet in Pre-Filter and use remaining hose to connect to the factory hard PCV line as shown:



Passenger side: Same as Cobra instructions above.

Lightning:

Passenger side: Pull out your PCV valve, screw Pre-Filter into grommet in valve cover and reinstall PCV valve into the grommet in the Pre-Filter as shown:



Thanks for the business. If you have any questions, please e-mail jay@JLTtruecoldair.com.